



Vreelin Eng. Inc.

747 Alice Ave.
Mountain View, CA
USA, 94041
Phone: (650) 386-5758
Fax: (650) 386-5758
E-mail:sales@vreelin.com
Website: www.vreelin.com

Features

- Logo Certified as a USB 2.0 High-Speed Device
- Also supports Full Speed
- 12 pin ULPI I/F to external USB2 PHY
- 32 Bit LMB Slave Interface
- 7 user endpoints plus control endpoint 0
 - user endpoints can be bulk, interrupt, or ISO
 - firmware configures each endpoint
- Memory mapped interface to the USB FIFO's
 - 8, 16 and 32 bit addressable
- Uses Block RAM (BRAM) for endpoint FIFO's
 - each FIFO is double buffered
 - Verilog source for FIFO memory provided for user optimization
- Complete logo certified mass storage device class firmware
- Windows device driver
- Demo applications

Table 1: Example Implementation Statistics

Family	Example Device	Fmax (MHz)	Slices ¹	IOB ²	GCLK	BRAM	MULT	DCM/DLL	MGT	PPC	Design Tools
Spartan-6™	XC6Sxxx-x	150	850			1+			N/A	N/A	ISE/EDK 12.3
Virtex 6™	XC6Vxx-x	150	750			1+			N/A	N/A	ISE/EDK 12.3
Virtex-5™	XC5Vxxx-x	150	750			1+			N/A	N/A	ISE/EDK 12.3

Core Facts	
Provided with Core	
Documentation	User Manual
Design File Formats	EDIF netlist, Verilog Wrapper
Constraints Files	None needed
Verification	Test Bench with HDL Source license only
Instantiation templates	Verilog
Reference designs & application notes	Reference Design on ML50X/ML40X series development boards with SMSC 3300 USB2 PHY Daughter Card Runs on Spartan 6/Virtex6 boards with custom PHY daughter card
Firmware	Complete Firmware stack provided
Core and Firmware is USB Logo Certified as a High-Speed USB device by the USB Implementor's Forum	




Figure 1: USB 2.0 Core Block Diagram

Applications

Adds a High-Speed USB 2.0 compliant device interface to the user's design. This interface is suitable for USB centric, high performance designs as well as legacy port replacement applications.

General Description

The Vreelin USB 2 High Speed Device core and associated software implement a complete end to end solution for connecting a Microblaze EDK design to a Windows host using high speed USB 2 transactions. Complete firmware for the Microblaze side is provided in standard C and a stable, high performance Windows device driver is provided for the PC. A demo application running under the Xilinx Microkernel (XMK) or standalone and an associated application running on Windows not only demonstrate the operation of the core, device driver, and firmware, but provide an excellent starting point for a user's design. The provided firmware also provides a mass storage device class demo that is a great starting point for mass storage applications.

Overall performance of the Vreelin device core is limited only by the speed of the Microblaze LMB bus and Windows. The core will run at maximum USB 2.0 high speed data rates. To achieve maximum performance, the core needs ~15 million 32 transactions per second over LMB. A Microblaze system running at 100MHz or greater will provide this level of performance. The LMB bus was chosen for this core due to the poor performance of LMB and PLB. This choice was guided by the designer of the Microblaze processor and other designer's experience with the EDK.

The core is implemented in approximately 750 slices on Virtex 5 and Virtex 6 and utilizes 1 or more block RAM's (BRAM's) configured as a dual port RAM with asynchronous clocked ports. Verilog source code is provided for the dual port RAM so that a designer can make appropriate tradeoffs in the dual port RAM's implementation. As supplied, the dual port RAM is implemented as 2K by 32 bit using 4 BRAM's. A 32 bit, byte addressable slave interface is implemented over LMB. The LMB interface supports one clock per write, 2 clocks per read on a random basis and 1 one clock per write, 2 clocks for the first read, and one for sequential reads on a block access basis.

On the USB side, the core uses the latest ULPI USB 2 PHY interface which requires only 12 pins. The core implements completely asynchronous dual clock domains. The USB SIE side of the core runs off of the ULPI PHY 60MHz clock and the LMB bus interface side runs off the LMB clock.

Note that for an understanding of USB 2.0 and all of its ramifications there are several sources. The USB 2.0 specifications available at www.usb.org is the standard definition, Mindshare and others have various books on the protocol, and Cypress Semiconductor has one of the best introductions in its "Easy USB FX User Manual" which can be downloaded at www.cypress.com. Read Chapter 1. Also please note that in this document and others, I refer to Windows. Microsoft for good or bad, defines the host O/S operating requirements that USB devices must meet. Linux and other O/S's are compatible.

Functional Description

USB 2.0 Protocol

A detailed description of the USB 2.0 protocol is beyond the scope of this data sheet. For that kind of description please refer to the USB 2.0 specification available from <http://www.usb.org> or to one of the many books that are available.

For purposes of this data sheet, the USB 2.0 protocol multiplexes many devices over a single, half duplex, bit serial bus. The bus is designed to be plug and play. The bus runs at 480 mega bits per second. The PC always controls the bus and send tokens to each device specifying the required action. Each device has an address on the USB 2.0 bus and has one or more endpoints that are sources or sinks of data. All devices have endpoint 0, the system control endpoint. Unlike all other endpoints, endpoint 0 is full duplex and single buffered. The Vreelin device core has seven additional endpoints for the user's application. When the PC wants to send data to a device's endpoint, it sends an OUT token, along with the address of the device and the endpoint number followed by the data. To receive data, the PC sends an IN token with the device address and endpoint number and waits for data from the device. To perform system level control functions, including plug and play, SETUP tokens are sent by the PC to endpoint 0, along with setup information.

The USB 2.0 core consists of 6 major hardware components and 4 software components.

USB 2.0 PHY

The PHY is user supplied. It can be any of the ULPI compliant PHY's on the market. The PHY's primary job is to handle the bit level serialization and de-serialization of USB 2.0 traffic. To do this it must also detect and recover the USB bus clock. This clock runs at 480MHZ and is too fast for practical implementation as programmable logic in the FPGA as well as in many ASIC's. Since 480MHZ is also high for a core clock, the PHY interfaces to the USB 2.0 core on a byte serial basis and generates a 60MHZ clock. This clock runs the SIE side of the USB 2.0 core. It can also be used to run the entire FPGA if desired.

Vreelin has had great success as well as achieved USB Logo Certification using the SMSC USB3300 ULPI PHY and several of SMSC's later variants.

USB 2.0 SIE

The USB 2.0 SIE (SIE) handles the serialization and de-serialization of USB traffic at the packet level and the multiplexing and demultiplexing of USB data to and from the core's endpoints. The SIE also handles USB 2.0 state transitions such as suspend, resume, and USB reset. The SIE implements the protocol specified in Chapter 8 of the USB 2.0 specification.

The SIE interfaces to the PHY using an industry standard set of handshaking lines called the ULPI interface. ULPI requires only 12 pins and is ideal for FPGA designs. Data to the FPGA from the USB is received from the PHY, error checked, and loaded into the appropriate area of the dual port RAM. Data from the FPGA to be sent over the USB is loaded from the block RAM, protocol wrapped and presented to the PHY a byte at a time when the protocol allows.

The status of current USB transactions are signaled by the SIE to the status register. Certain conditions can be enabled through the interrupt enable register to generate an interrupt on the LMB bus.

Dual Port RAM

The Dual Port RAM is the data storage area between the USB SIE and the LMB bus interface. It is fully dual port and dual clocked. Port A is used by the SIE, port B is used by the LMB bus interface. For performance reasons, both ports are 32 bits wide. Port A is clocked by the ULPI PHY clock at 60MHz and port B is clocked by the LMB bus clock at any speed desired. There is no required phase relationship between the clocks.

Data from USB is stored in the appropriate locations in Dual Port RAM by the SIE through port A. The user's firmware or hardware accesses this data through port B over the LMB. Data to the USB is loaded by the user through the LMB to port B into the appropriate locations in the Dual Port RAM. When the PC requests data from the device, the SIE accesses this data from port A.

The Dual Port RAM is "seen" by the SIE as eight endpoint FIFO's, plus a control register area that defines how the memory is laid out. Each FIFO is implemented as ping pong buffers to help support the high throughput possible with USB 2.0. One buffer can be used for a current USB transaction while the other buffer is available to the user application for processing. The storage areas are treated as FIFO's only from the SIE's point of view. The user's firmware or hardware can access the storage as ordinary RAM over LMB. Dual Port RAM based registers are located in the lower 64 bytes of Dual Port RAM that control the layout of each endpoint's FIFO's in Dual Port RAM, the communications direction (OUT or IN) of the endpoint, the endpoint's type (Bulk/Interrupt or ISO), and certain internal state information.

To provide flexibility to the designer and to minimize the resources used by the USB 2.0 Core, the Verilog source code for the dual port RAM implementation is provided. The designer can then optimize for his particular needs. As supplied, 4 2kx8 BRAM's are used. More or less can be used as long as port A is 32 bit addressable and port B is 8, 16, and 32 bit addressable.

LMB Bus Interface

The LMB bus interface connects port B of the dual port RAM and the Control & Status Registers to the LMB bus. This is a slave interface that looks like RAM. Byte, half word and word transfers are supported.

Control & Status Registers

The Control and Status Registers control operation of the USB 2.0 core, report the core's status, sets the USB function address, indicates buffer ready condition to the USB SIE, and enable interrupts. These registers are implemented as registers in hardware, not block RAM. They are accessed over LMB in the upper 16K byte address space of the core. They are the address register, control register, status register, current USB frame number register, interrupt enable register, buffer ready register and the mode control register.

The address register contains the function address of the USB 2.0 core. It is written by firmware and must be set in accordance to Chapter 9 commands from the host.

The control register currently only implements a master enable bit. Until this bit is set, the SIE is held in reset and will not respond to USB traffic.

The status register reports on current USB conditions such as USB Reset, USB Suspend, USB Resume, USB Disconnect, setup packet received, and buffer complete status for each endpoint and each buffer.

The frame number register reports the most current USB SOF packet received. Both major 1MS frames and minor 128 microsecond frames are reported.

The interrupt enable register determines which status register events and which endpoints cause an interrupt to the LMB. Reading the status register clears any current interrupt.

The buffer ready register indicates the ready status of each endpoint's two FIFO buffers to the SIE. Only buffers that are indicated as ready will be loaded or unloaded by the SIE in response to USB transactions.

EDK Verilog Wrapper

The Verilog wrapper is used by the EDK to set the address range for the USB 2.0 core in the LMB address map. The wrapper instantiates the core and does the master address decode for LMB bus transactions.

Firmware Overview:

The firmware has 3 main areas of operation. First, the firmware implements all of the requirements of the USB 2.0 specification chapter 9, otherwise known as the "chapter 9 firmware" that operates against endpoint 0. Second, the firmware provides both low level primitives and high level abstraction interfaces to the user endpoints (1 to 7). Unix style stream I/O interfaces such as USBRead, USBWrite, and USBIoctl are provided for each of the user endpoints. Third, the firmware handles gross USB conditions such as USB Reset, Suspend, Resume, and Disconnect.

Chapter 9 Support:

Chapter 9 of the USB specification concerns itself with the enumeration process with the USB host the device is plugged into. This process is complex and takes a newly plugged in USB 2.0 high speed device to the configured or enumerated state. In this state, the USB Host knows what the device implements and how to talk to it. During normal operation, there are other endpoint 0 communications that can take place that the Chapter 9 firmware will handle. For the most part, this is transparent to the designer. All that is required is for the microprocessor system to either provide an interrupt handling routine that services the device core's status register interrupt and dispatches to the appropriate firmware or polls the status register on a frequent enough interval and dispatches to the appropriate firmware.

User Endpoint Firmware:

Endpoints 1 to 7 make up the user endpoints of the device core. Each endpoint may be programmed to be either an IN or OUT endpoint (IN to the USB Host, OUT from the USB Host); may have packet sizes of from 2 to 512 bytes each for non-ISO endpoints and from 2 to 1024 bytes each for ISO endpoints. There is no requirement to use all of the user endpoints.

The Standard Configuration:

In its simplest use case, the firmware defaults to the standard configuration. The standard configuration is designed to make it easier for a designer to add a USB interface to a design. Endpoints 1 to 3 are setup "out of the box" as OUT endpoints (from the HOST) as non-ISO and 512 byte packet size. Likewise, endpoints 4 to 6 are setup as IN (to the HOST) as non-ISO and 512 byte packet size. Endpoint 7 is setup as an INTERRUPT IN (to the host) endpoint with a packet size of 16 bytes and is intended to be used for device status to the host. Using the UsbRead, UsbWrite, and UsbIoctl function calls, Unix like stream I/O is provided to the designer over the user endpoints back to the host.

In addition, the standard configuration includes a tested Windows XP device driver that supports the above endpoint configuration and a user level support library and demo application. With the Host set of software plus the provided firmware, the designer can add 6 high speed USB 2.0 endpoints to his design, plus a status endpoint and access all of them from application space under Windows XP out of the box.

USB Gross Condition Handling:

Since USB is “Plug and Play” code is provided to handle the Plug and Play aspects of USB. USB Disconnect happens when the user unplugs the USB cable. The firmware will properly shut down I/O and return the core to the USB unenumerated state waiting for a new plugin. USB Reset happens on host command. Similar firmware comes into play as for USB Disconnect. USB Suspend / Resume handles the go to sleep and wakeup aspects of USB and safely suspends and resume I/O operation.

In addition using the USBloctl high level abstraction interface, user provided call backs can be installed the will be “called out” on any of the above conditions to handle user specific situations. Please note that all of these callbacks are called at interrupt service time (if interrupts are being used) and should be short and to the point.

Non Standard Configuration:

If the standard configuration will not provide the needed functionality for a designer, then the firmware provides several options to produce non standard configurations.

Modify the Standard Configuration:

This method will work best when the desired configuration is not too different from the standard configuration. Perhaps the number or direction of endpoints are different or the packet sizes need to be tweaked. This approach works as follows:

1. The designer must modify the descriptors provided for the standard configuration in usb.c using the structure definitions in usb.h. These descriptors must match the desired USB configuration.
2. Call USBInit as usual. This loads the modified descriptors into the firmware.
3. Then appropriate calls must be made to USBloctl to set each endpoint’s characteristics to match what was set in the modified descriptors. These calls can include setting the base address in dual port RAM for each endpoint’s buffers and the size of those buffers.

Warning:

The designer must be careful in the assignment of endpoint base addresses and sizes since there is no contention checking between endpoints in the dual port RAM. The core will happily DMA anywhere into dual port RAM it is told to for an endpoint including right over other endpoint’s buffer areas.

4. Use the other USBloctl calls to set call backs for USB Reset, Suspend, and Disconnect.
5. Continue with normal startup and operation

The calls UsbRead, UsbWrite, and other Usbloctl calls are still available once the endpoints have been customized as long as the right call is made to the right endpoint – I.E. – USBRead to an OUT endpoint, USBWrite to an IN endpoint for example.

Create Completely New Descriptors:

If the designer needs a USB configuration that is completely different from the standard configuration supplied, then completely different USB descriptors will be needed. This approach will require a considerably higher understanding of USB at several levels. However, using the files usb.c and usb.h it is feasible to build something unique without writing firmware from scratch. Some things to consider:

1. Look at the layout of the descriptors at the top of usb.c and their corresponding structure definitions in usb.h.
2. Look at the function usbinit in usb.c. Follow it's logic flow and notice how the descriptors are copied into data structures. These descriptors are presented to the usb host on demand through the chapter 9 code in the firmware. The chapter 9 function, GetDescriptor parses chapter 9 requests and selects the appropriate descriptor for transmission over USB. Both usbinit and GetDescriptor may have to be modified.
3. The function Init_Usb_Interfaces will have to be modified to match the endpoint configurations in the new descriptors.
4. The standard configuration API calls USBRead, USBWrite, and USBIoctl can still be used if desired.

Write New Firmware:

The files usb.c and usb.h contain a great deal of code that can be reused, if new firmware is desired. Most of the low level functions are quite useful in a customer firmware situation. Complete hardware interface definitions are provided later in this document.

In any of the above cases, Vreelin Engineering is available on consulting basis to help with customization.

Whatever is done on the device (core) side, must match what is supplied with the device driver and INF file on the PC side. Again this is a non trivial exercise. Vreelin is available to help with this on a consulting basis.

If even more customization is needed, see the firmware source code. Low level primitives are provided to manipulate all endpoints as well as move data in and out of the dual port RAM. Vreelin is available on a consulting basis to customize any of this for special designer needs.

Host Software

The vast majority of hosts will be Windows PC's. A completely functional Windows XP device driver that supports the standard configuration is supplied in source and object form with this release. This device driver brings all 7 user endpoints out to ring 3 application space. A support library and demo application is provided to show how to use the device driver.

The device driver will handle the following changes in the usb core's firmware without modification:

1. endpoint IN or OUT
2. endpoint size
3. endpoint interrupt, or BULK
4. number of active endpoints (up to the max of 7)

Note that the Windows XP device driver does not currently support ISO transactions. If ISO endpoint transactions are required or if integration with other Windows XP system components are required, then a custom device driver will be needed. Vreelin Eng. Inc. is available on a consulting basis to develop such device drivers.

Firmware High Level API:

All of the standard configuration firmware and it's API calls are contain in usb.c. All of the data definitions and structures are contained in usb.h. These files are located in the ml401/hal/src tree. In addition a simple demo firmware application usbdemo1.c is also located in ml401/hal/src.

void USBInit(usb_dev* dev, int base, int irq)

1. usb_dev* dev pointer to USB dev structure (a global in user code)
2. int base base address of USB core's on microprocessor bus
3. int irq interrupt assigned to the core

USBInit will perform all one time core initialization including registering the core's interrupt handler with the supported RTOS or HAL. The usb_dev structure should be allocated in the user's global area and must be valid duiring interrupt processing time.

int USBWrite(end_point, NoBlock, ptr, len)

1. int end_point endpoint number 1 to 7
2. int NoBlock 1 implies do not block on space available
3. char * ptr pointer to the buffer to write from
4. int len maximum number of bytes to write
5. returns number of bytes written

This routine will write up to len bytes from the memory addressed by ptr and send it to the USB endpoint buffer as space is available. If NoBlock = 0, then USBWrite will suspend the caller until all of the requested data has been written. If NoBlock = 1, then only the available data will be written including 0 bytes if no buffer space is available. USBWrite will return the number of bytes written in all cases.

int USBRead(end_point, NoBlock, ptr, len)

1. int end_point endpoint number 1 to 7
2. int NoBlock 1 implies do not block on data available
3. char * ptr pointer to the buffer to read into
4. int len maximum number of bytes to read
5. returns number of bytes read

This routine will read up to len bytes from end_point. If NoBlock is set to 1, then only the number of bytes available up to len will be read. Otherwise, USBRead will block (ether suspend the task or spinloop depending on the environment) until the requested number of bytes in len are available. US

int USBIoctl(end_point, int request, pvoid)

1. int end_point endpoint number 0 to 7
2. int request IOCTL request number, defined in usb.h
3. void *pvoid generic pointer to specific parameters

Just as in most O/S's, USBIoctl is the catch all call. Request determines the functionality of the call.

Request applicable to the user endpoints (1 to 7):

1. I_SET_OUT_IN

Pvoid points to an unsigned int that is 0 for OUT and 1 for IN. Note that an endpoint set to OUT receives data from the HOST and one set to IN sends data to the host.

2. I_SET_VALID

Pvoid points to an unsigned int that is 1 for VALID and 0 for non VALID. An endpoint must be set to VALID to operate. If set to non VALID, the endpoint will ignore all I/O from the host. VALID is a master enable bit for the endpoint.

3. I_SET_STALL

PVOID points to an unsigned int that is 1 for STALL and 0 for non STALL. If STALL is set, then all I/O attempts from the host for this endpoint will receive a STALL response. STALL is used in USB to indicate a need for host interaction. It is not used often. For normal operation, set the endpoint to non STALL.

4. I_SET_ISO

PVOID points to an unsigned int that is 1 for ISO and 0 for non ISO. Isochronous endpoints have special characteristics. The endpoint may have a max packet size of up to 1024 as opposed to 512 for BULK. Packets are not handshaked and are not retried.

5. I_SET_BASE

PVOID points to an unsigned int that contains the offset in 32 bit words from the beginning of dual port RAM to the start of the first packet buffer of two for the endpoint. It is the designer's responsibility to layout the dual port RAM and to make I_SET_BASE and I_SET_SIZE calls that do not result in buffer overlap or writing of packet data to undesired locations.

6. I_SET_SIZE

PVOID points to an unsigned int that contains the size of the endpoints packet buffers in bytes. Non ISO user endpoints can be up to 512 bytes in size. ISO endpoints can be up to 1024 bytes in size. Two packet buffers will be allocated in dual port RAM one after the other, so that if a designer uses this call with a value of 512 for example, 1024 bytes will be reserved.

NOTE: Functions 1 to 6 require that an appropriate set of USB descriptors be supplied to the firmware using UsbIoctl calls to endpoint 0 as described in this document below.

Requests applicable to endpoint 0 only:

1. I_STARTUSB

This call starts the core. The core may be stopped and started at any time. However, stopping the core during USB enumeration or other host driven event times will cause unpredictable results. This call is primarily intended to allow the designer to setup the core characteristics with the core stopped and then to release the core for operation.

2. I_STOPUSB

This call stops the core. Not intended for normal use.

3. I_SETUSBRESETCB

Sets a user callback to be called when a USB Reset happens. PVOID points to a structure defined in usb.h that has a function pointer and a user data pointer that will be passed to the callback when called. The call back provided will be called at interrupt time, so it should be short and to the point.

4. **I_SETUSBDISCONCB**

Sets a user callback to be called when the USB cable is unplugged. PVOID points to a structure defined in usb.h that has a function pointer and a user data pointer that will be passed to the callback when called. The call back provided will be called at interrupt time, so it should be short and to the point.

5. **I_SETUSBSUSPENDCB**

Sets a user callback to be called when the USB goes into suspend. PVOID points to a structure defined in usb.h that has a function pointer and a user data pointer that will be passed to the callback when called. The call back provided will be called at interrupt time, so it should be short and to the point.

6. **I_SETUSBCONFIGCB**

Sets a user callback to be called when the firmware has received and accepted a configuration request from the host. PVOID points to a structure defined in usb.h that has a function pointer and a user data pointer that will be passed to the callback when called. The current configuration number will be passed as well. The call back provided will be called at interrupt time, so it should be short and to the point.

7. **I_SETUSBSOFCB**

Sets a user callback to be called when a USB Start of Frame token is received. Note this is the 1 millisecond master start of frame, not the 125 microsecond sub frame. PVOID points to a structure defined in usb.h that has a function pointer and a user data pointer that will be passed to the callback when called. The current frame number will be passed as well. The call back provided will be called at interrupt time, so it should be short and to the point.

8. See usb.c and usb.h for the rest of the IOCTL calls.

Windows user level API

All of the files composing the Windows XP device driver, support library and demo application are contained in device_drivers\vreelindd. The device driver files are in the sub directory driver, and the demo application files and support library are in the subdirectory usbapp. The support library is usb.cpp and usb.h, the demo application is usbapp.cpp. The demo application is a Windows XP console application.

DWORD USBInit(void)

Finds the usb device in Windows XP device name space and performs magical incantations to get the device ready for individual calls to USBOpen for the endpoints. If the magic works, returns ERROR_SUCCESS, otherwise, the call returns the error encountered.

DWORD USBOpen(int end_point)

Opens a handle to the specified endpoint, end_point. This function call CreateFile, passing in a name space path to the individual endpoint. Returns ERROR_SUCCESS on successful open, otherwise the Windows XP system error code is returned.

DWORD USBClose(int end_point)

Closes the handle to the specified endpoint, end_point.

DWORD USBRead(int end_point, char *ptr, int len)

1. Int end_point endpoint to read from

- | | |
|--------------|---------------------------------|
| 2. Char *ptr | buffer pointer to read into |
| 3. Int len | maximum number of bytes to read |

Will read the number of bytes requested from the specified endpoint into the buffer pointed to by ptr. The default settings will suspend the calling thread until the number of bytes read are complete. Returns on completion or error such as the USB device being unplugged. Will return the number of bytes read or the error code if an error occurs.

DWORD USBWrite(int end_point, char *ptr, int len)

- | | |
|------------------|----------------------------------|
| 1. int end_point | endpoint to write to |
| 2. char *ptr | buffer to write from |
| 3. int len | maximum number of bytes to write |

Writes the specified number of bytes to the endpoint from the buffer pointed to by ptr. Will suspend the caller until len bytes are written unless appropriate DeviceIoControl calls are made through USBIoctl. Returned the number of bytes written or the system error code if an error occurs.

DWORD USBIoctl(int end_point, DWORD request, void *inbuffer, DWORD inbuffersize, void *outbuffer, DWORD outbuffersize)

- | | |
|------------------------|----------------------|
| 1. int end_point | endpoint to control |
| 2. DWORD request | DeviceIoControl code |
| 3. void *inbuffer | input buffer |
| 4. DWORD inbuffersize | input buffer size |
| 5. void *outbuffer | output buffer size |
| 6. DWORD outbuffersize | output buffer size |

Passed request through to the specified endpoint using DeviceIoControl. See the documentation for DeviceIoControl. Some requests are generic to all file I/O under Windows and would apply here. Others are device driver specific. The Windows XP device driver supplied with the core supports the following DeviceIoControl calls:

1. IOCTL_RESET_PIPE

This call will cause all I/O operations and the data toggle bit to be reset. Not normally needed

2. IOCTL_GET_CONFIG

Will return in the outbuffer the complete configuration descriptor unless the descriptor is larger than outbuffersize, in which case it will return outbuffersize bytes of the descriptor.

3. IOCTL_RESET_DEVICE

Performs a complete reset of the entire device resetting all endpoints. Not normally needed.

Usbhaldemo1.c and Usbapp.c

Usbhaldemo1.c implements a demo firmware application that uses the firmware high level API as implemented in usb.c and usb.h. Usbapp.cpp similarly uses the ring 3 user API to talk to the Windows XP device driver. The two programs “play” together and are meant as a starting point for a designer’s application.

Core Modifications

The only modification that can be done with a netlist license is the implementation of the dual port RAM. The Verilog source code is provided in the file dual_port_ram.v.

Core I/O Signals

The USB 2.0 core is an LMB slave compliant interface intended to be used with the Xilinx EDK. Note that ULPI_Data is a bi-directional data bus. The EDK conventions require all bidirectional buses to be implemented by the EDK platgen utility. Therefore, the USB 2.0 core instead uses ULPI_Data_I and ULPI_Data_O controlled by ULPI_Dir.

Table 1: Core I/O Signals.

Signal	Signal Direction	Description
ULPI Interface		
clock	Input	60MHZ ULPI clock for SIE generated by USB PHY
ULPI_Dir	Input	When High, the PHY is outputting to ULPI_Data, the core see this on ULPI_Data_I
ULPI_Next	Input	Data in or out on ULPI_Data is required to be valid on the next rising edge of clock
ULPI_Stop	Output	When the core is transmitting on ULPI_Data, ULP_Stop going high will signal the end of transmission.
ULPI_Data_I[7:0]	Input	ULPI Input data bus – merged with ULPI_Data_O and tri-state control in the EDK to form ULPI_Data
ULPI_Reset	Output	When high causes the external ULPI PHY to reset. Used to recover from PHY error conditions
LMB Bus Interface		
LMB_Clk	Input	LMB Bus clock
LMB_Rst	Input	LMB Bus Reset – resets entire core
LMB_Abus [31:0]	Input	LMB Address bus bits 31 to 15 used for decode of core's address space
LMB_BE[3:0]	Input	LMB byte lane selects, each bit corresponds to one of the 4 byte lanes on the LMB data bus, supported by the core in the block RAM address space, not in the hard register space
LMB_Data_In [31:0]	Input	LMB Data bus into the core
LMB_RNW	Input	R/W select line, 0 = write, 1 = read
LMB_select	Input	LMB bus select line, 1 = valid cycle for this core, 0 = invalid
LMB_seqAddr	Input	Not used
LMB_Data_Out [31:0]	Output	LMB Data bus out of the core
LMB_ErrAck	Output	Not used – we don't have any errors!
LMB_Retry	Output	Not used – we are very timely
LMB_TlmeoutSup	Output	Not used – see above
LMB_XferAck	Output	Used to acknowledge that the requested LMB bus cycle is complete

LMB Memory Map

The following is the memory layout of the USB 2.0 Core as seen from the LMB bus. The base address of the core is set by the EDK utility platgen using data from the file system.mhs supplied in the EDK build tree.

Microprocessor Bus Memory Map (Port B of Dual Port RAM)

Offset	Description
0 to 0x80	Endpoint confuration space
0x80 to 0x87	Setup packet storage location (8 bytes)
0x88 to 0x3fff	RAM for endpoint buffers Allocation is controlled by settings in endpoint configuration space.
0x4000 to 0x7fff	Hard coded register space.
0x4000	USB Address
0x4004	Control
0x4008	Status
0x400C	Current USB frame number
0x4010	Interrupt Enable
0x4014	Buffer Ready
0x4018	Mode Control (for USB certification)

Note all offsets are byte offsets.

Endpoint Configuration Space

Each endpoint has 4 32 bit locations located sequentially and arranged by endpoint number. I.E.:

Offset	Desc.
0x00	Endpoint 0
0x10	Endpoint 1
0x20	Endpoint 2
0x30	Endpoint 3
0x40	Endpoint 4
0x50	Endpoint 5
0x60	Endpoint 6
0x70	Endpoint 7

For each endpoint there are four 32 bit words defining the endpoints behaviour:

Offset	Desc.
0x00	Endpoint Config Status Register
0x04	Unused, but reserved
0x08	Buffer 0 count: 0 to 1024
0x0c	Buffer 1 count: 0 to 1024

Endpoint Config Status Register

BIT	Name	SET	CLEAR	Comments
31	EP_VALID_BIT	Endpoint operations are allowed	No endpoint operations are allowed	Master enable / disable bit for the endpoint

USB2.0 High-Speed Device Interface for Xilinx EDK

30	EP_STALL_BIT	Endpoint is stalled	Endpoint is not stalled	When set, a STALL is the only response to the host for this endpoint
29	EP_OUT_IN_BIT	Endpoint responds to IN transactions	Endpoint responds to OUT transactions	In/Out is with respect to the host.
28	EP_ISO_BIT	ISO endpoint	Non ISO endpoint	ISO endpoints do not send or expect Ack's or Nak's
27	EP_DATA_TOGGLE_BIT	Data toggle is 1 and will expect or send a DATA 1 packet	Data toggle is 0 and will expect or send a DATA 0 packet	Used as weak form of synchronization.
26	EP_BUFFER_SELECT_BIT	Current buffer is the second buffer	Current buffer is the first buffer	Implements ping pong buffers
25	EP_PACKET_SIZE_MS	This field allows up to 1024 byte packets		MSB of the packet size
15	EP_PACKET_SIZE_LS			LSB of the packet size
17	EP_PACKET_SIZE_QWA			Used to index RAM in 32 bit chunks
12	EP_BASE_MS			MSB of the base offset in RAM of the buffers
0	EP_BASE_LS			LSB of the base offset in RAM of the buffers

Hard Coded Registers:

USB Address Register:

Contains the Host assigned USB address of the device. Takes on values from 0 to 127. An address of 0 implies that the device is unenumerated and is the default address of all USB devices at plug in time. Reset by hardware to 0. Program by the microprocessor under supplied Chapter 9 firmware control.

Control Register:

Only one bit, bit 31. When clear, the USB SIE is paused and will not respond to any USB activity. When set, the SIE operates normally.

Status Register

The status register reports status on the operation of the USB device core. It is an auto clear register. That is, when the microprocessor reads the status register, all bits reported are cleared.

Bit	Name	Set	Clear	comments
23	USB Reset	USB Reset active	Normal	Will remain set for up to 3 ms
22	USB Suspend	USB Suspend active	Normal	Will remain set for as long as suspend which can be hours

21	USB Disconnect	USB Cable unplugged	USB Connect	USB detach detection
20	FIFO Buf Rdy	EP 0 Pkt Received		
19	FIFO Buf Free	EP 0 Pkt Transmitted		
18	Setup Packet	EP 0 Setup Pkt Rcv'ed		
17	SOF Packet	Start of Frame Rcv'ed Value in Start of Frame Register		SOF's happen every 125 us in high speed mode!
16	High Speed	USB in high speed	USB in full speed	
15	EP 7 2 nd Buf Comp	Buffer Complete	Not processed	
14	EP 6 2 nd Buf Comp	Buffer Complete	Not processed	
13	EP 5 2 nd Buf Comp	Buffer Complete	Not processed	
12	EP 4 2 nd Buf Comp	Buffer Complete	Not processed	
11	EP 3 2 nd Buf Comp	Buffer Complete	Not processed	
10	EP 2 2 nd Buf Comp	Buffer Complete	Not processed	
9	EP 1 2 nd Buf Comp	Buffer Complete	Not processed	
8	Not Used			EP 0 has only 1 buffer and it is bir directional
7	EP 7 1 st Buf Comp	Buffer Complete	Not processed	
6	EP 6 1 st Buf Comp	Buffer Complete	Not processed	
5	EP 5 1 st Buf Comp	Buffer Complete	Not processed	
4	EP 4 1 st Buf Comp	Buffer Complete	Not processed	
3	EP 3 1 st Buf Comp	Buffer Complete	Not processed	
2	EP 2 1 st Buf Comp	Buffer Complete	Not processed	
1	EP 1 1 st Buf Comp	Buffer Complete	Not processed	
0	EP 0 Buf Comp	Buffer Complete	Not processed	EP 0 has only 1 buffer and it is bir directional

USB Frame Number Register:

The frame number register is composed of 2 fields, frame and microframe. Frames are sent once every one millisecond and denote the beginning of a USB frame. All host scheduling starts at start of frame time. The microframe field is the result of additional start of frame tokens sent once every 125 microseconds. Because of the potentially high rate interrupts this can generate when the Usb is in high speed mode, interrupt enable of start of frame should be used with caution. Frame count values are 11 bits and microframes are 3 bits.

Bit	Name	Comments
13	Frame MSB	0 to 2047
3	Frame LSB	
2	Micro Frame MSB	0 to 7
0	Micro Frame LSB	

Interrupt Enable Register:

The interrupt enable register allows specific bits in the status register to generate an interrupt. There is also a master enable bit so that all interrupts can be disabled at once. When the status register is read, and there is no further driver for the status bits causing the interrupt, the interrupt condition is cleared. Alternatively, the interrupt enable bit can be cleared to prevent a long duration condition such as USB Reset from continuously generating an interrupt.

Bit	Name	Comments
31	Master enable	Enables setting of all other enables
23	USB Reset IE	Enables USB Resets to generate an IRQ
22	USB Suspend IE	Enables USB Suspend to generate an IRQ
21	USB Disconnect IE	Enables USB disconnects to generate an IRQ
20	FIFO Buf Rdy IE	A received Data Packet on EP 0 will generate an IRQ
19	FIFO Buf Free IE	A successfully transmitted data packet on EP 0 will generate an IRQ
18	SETUP Pkt IE	A received setup packet will generate an IRQ
17	SOF Pkt IE	Start of Frame will generate an IRQ
16	High Speed IE	When the bus is in High Speed an IRQ is generated
15	EP 7 2 nd Buf Complete IE	IRQ on Buffer operation successful
14	EP 6 2 nd Buf Complete IE	IRQ on Buffer operation successful
13	EP 5 2 nd Buf Complete IE	IRQ on Buffer operation successful
12	EP 4 2 nd Buf Complete IE	IRQ on Buffer operation successful
11	EP 3 2 nd Buf Complete IE	IRQ on Buffer operation successful
10	EP 2 2 nd Buf Complete IE	IRQ on Buffer operation successful
9	EP 1 2 nd Buf Complete IE	IRQ on Buffer operation successful
8	Not used	
7	EP7 1 st Buf Complete IRQ	IRQ on Buffer operation successful
6	EP6 1 st Buf Complete IRQ	IRQ on Buffer operation successful
5	EP5 1 st Buf Complete IRQ	IRQ on Buffer operation successful
4	EP4 1 st Buf Complete IRQ	IRQ on Buffer operation successful
3	EP3 1 st Buf Complete IRQ	IRQ on Buffer operation successful
2	EP2 1 st Buf Complete IRQ	IRQ on Buffer operation successful
1	EP1 1 st Buf Complete IRQ	IRQ on Buffer operation successful
0	EP0 1 st Buf Complete IRQ	IRQ on Buffer operation successful

Buffer Ready Register:

Each buffer for each endpoint has a corresponding buffer ready bit in this register. The firmware sets each bit when that buffer is ready for either USB IN or USB OUT traffic. Until that bit is set, an attempted IN or OUT to the buffer will result in a NAK back to the host. Note that the ability of a buffer to handle an IN or OUT is determined by the EP_OUT_IN_BIT in the corresponding endpoint's ep_config_status word in low memory. Also note that endpoint 0 has only one buffer and that it handles IN's or OUT's. This is per the USB specification.

Bit	Name	Comment
15	EP 7 2 nd Buffer Ready	Set when available for IN or OUT
14	EP 6 2 nd Buffer Ready	Set when available for IN or OUT
13	EP 5 2 nd Buffer Ready	Set when available for IN or OUT
12	EP 4 2 nd Buffer Ready	Set when available for IN or OUT

11	EP 3 2 nd Buffer Ready	Set when available for IN or OUT
10	EP 2 2 nd Buffer Ready	Set when available for IN or OUT
9	EP 1 2 nd Buffer Ready	Set when available for IN or OUT
8	N/A	End point 0 has only one buffer
7	EP 7 1 st Buffer Ready	Set when available for IN or OUT
6	EP 6 1 st Buffer Ready	Set when available for IN or OUT
5	EP 5 1 st Buffer Ready	Set when available for IN or OUT
4	EP 4 1 st Buffer Ready	Set when available for IN or OUT
3	EP 3 1 st Buffer Ready	Set when available for IN or OUT
2	EP 2 1 st Buffer Ready	Set when available for IN or OUT
1	EP 1 1 st Buffer Ready	Set when available for IN or OUT
0	EP 0 Buffer Ready	Set when available for IN or OUT

Test Mode Register:

The Usb Impelmentor's Forum, the organization that controls USB logo certification, requires all USB 2.0 device that operate at high speed to support the following test modes:

1. Test Mode J: Sends a continuous Chirp J.
2. Test Mode K: Sends a continuous Chirp K.
3. Test Mode NAK: Send a NAK in response to any valid packet. Ignor invalid packets.
4. Test Mode Packet: Sends the "Luerker" packet over and over forever.

Each of these test modes are started by Chapter 9 comands via the firmware. Once received the test mode register is set to the desired test mode. To exit the test mode requires a hardware reset. Test mode 0 is normal operation.

Verification Methods

The USB 2.0 core can be verified against any standard PC running Windows 2000 or XP using one of the supplied reference designs and the Xilinx ML401 or ML403 development boards and the SMSC USB3300 PHY daughter card.

A complete USB 2.0 test bench environment for simulation is available from Vreelin Eng. Inc. when the HDL source license is purchased.

How to use the USB 2.0 Core in the Xilinx EDK:

The distribution package includes the following directories:

1. pcore - This is the complete component tree for the hardware.
2. hal – This directory contains the firmare source code and an example firmware app.
3. MI505 – This directory contains a complete EDK project for use with the Xilinx ML505 development board and the SMSC USB3300 PHY daughter card. The project is already configured to build a demonstration system using the USB 2.0 Core, the supporting firmware, and the Xilinx Microkernel (XMK).

4. vreelindd – This directory contains both the source code and the install files for the Windows XP device driver vreelindd.sys and demonstration application usbapp.exe. An INF file for installation of the device driver is also included.

The easiest way to start using the USB 2.0 Core with the EDK is to use the ml505 project tree. Using Platform Studio or manual editing of the configuration files system.mhs and system.mss, a user specific system can be created. The other way is to copy the pcores and hal directories to a user created project tree created manually or with base system builder and to use Platform Studio to add the core. The USB 2.0 core is called USBIF.

The Hardware I/O Port Option

The Hardware I/O port option (HWIF) provides a very high speed direct interface to the USB SIE from user provided hardware. Any of the 7 user endpoints may be redirected to the HWIF port. In conjunction with the Vreelin supplied Windows device driver, sustained throughput of 50 megabytes a second is possible.

The HWIF redirects USB packet I/O from the internal core ping pong buffers to the HWIF port when bit 14 (EP_HW_IO) is set in an endpoint's configuration register by the microprocessor firmware. Packet data from the PC (OUT's) or to the PC (IN's) can be redirected. Redirection can be changed on the fly by the firmware. More than one endpoint can be redirected at a time. The HWIF port interface includes the endpoint number so that user supplied hardware can differentiate endpoint traffic. When packet I/O is redirected to the HWIF port, it is the responsibility of the user supplied hardware to buffer data appropriately and to keep up with the interface.

HWIF Port Signals

Signal	Signal Direction	Description
clock	Input	60MHZ USB PHY clock – all signals active on rising edge
reset	Input	Master reset
HWIF_Active	Input	High when packet traffic to HWIF is active
HWIF_EP_Adrs[2:0]	Input	The endpoint number of the current packet. Can be used by user hardware to decode when data source or sink to use.
HWIF_Next	Input	High when next byte in or out is valid data bus
HWIF_Error	Input	High when an transmission or reception error has occurred. This indicates the current receive packet must be discarded or the current transmit packet must be resent. Used by user hardware to control buffering.
HWIF_Data_Out [7:0]	Input	8 bit data in. Valid when HWIF_Next is high, one byte per clock
HWIF_Data_In [7:0]	Output	8 bit data out. Next byte must be valid on next clock when HWIF_Next is high
HWIF_Ready	Output	Asserted by user hardware within 3 clocks after HWIF_Active is high to signal user hardware ready with data. If this does not happen, the USB SIE will send a NAK in response to the current packet. Can be used with the HWIF_EP_Adrs to selectively indicate ready or not ready for an end point.
HWIF_Stall	Output	Asserted by user hardware when a STALL condition is present. Will cause the USE SIE to send a STALL in response to any packet. Can be used with the HWIF_EP_Adrs to selectively STALL an end point.

A demonstration hardware application is provided. The file is hwif_wrap.v. It is well commented. This file implements a wrap application where data from USB is sinked over endpoint 1 into a ping pong memory and sourced over endpoint 4 back to USB.

Sequence to Sink Data from USB

1. Wait for HWIF_Active to go high
2. If ready to receive data, assert HWIF_Ready within 3 clocks
3. Sink one byte of data from HWIF_Data_Out on each clock that HWIF_Next is high
4. When HWIF_Active goes low, the transfer is complete. If HWIF_Error is high, then the transfer's CRC16 failed and the packet should be discarded. If HWIF_Error is high it will drop on the next clock.
5. If HWIF_Error was low indicating that the packet was received successfully, the last two bytes store are the CRC16 value and should be discarded.

Sequence to Source Data to USB

1. Wait for HWIF_Active to go high
2. If ready to transmit data, assert HWIF_Ready within 3 clocks
3. Source one byte of data to HWIF_Data_In on each clock that HWIF_Next is high
4. When data from the current packet is finished, drop HWIF_Ready on the clock following the last byte of transfer. Note that zero length packets are legal as are short length packets. The maximum length packet that may be transferred will depend on the setup of the endpoint's descriptor by the firmware. Maximum for Bulk is 512 bytes.
5. Wait for HWIF_Active to go low. This may take several microseconds as the USB SIE is waiting for the host to ACK, NAK, or timeout. If the host received the packet correctly, I.E., it ACK'ed the transfer, then when HWIF_Active goes low, HWIF_Error will also be low. If an error occurs, HWIF_Error will be high and the packet will need to be re-transmitted on the next packet transaction against this endpoint. If HWIF_Error was high, it will go low on the next clock.

Use of HWIF_EP_Adrs

HWIF_EP_Adrs identifies the endpoint number of the current HWIF transaction. It is valid while HWIF_Active is high. HWIF_EP_Adrs would allow user supplied hardware to support more than one endpoint.

Use of HWIF_Stall and HWIF_Ready

HWIF_Ready normally indicates dynamic status of the user's hardware to sink or source data. However HWIF_Ready and HWIF_Stall can be used to indicate static not ready or Stall conditions. As long as HWIF_Ready is low, any packet activity against the HWIF port will be NAK'ed. As long as HWIF_Stall is high, any packet activity against the HWIF port will be STALL'ed.

Clock Implications

The HWIF port clock runs at 60MHZ and is derived from the USB PHY. It also runs the USB SIE. All transactions and all signals of the HWIF port are synchronous to clock.

